



INSTALLATION

1. Insert main body, no need to insert two side leather baffle first



2. Adjust main body to an appropriate position so power hole and USB interface can be easily used. Note: for some Model S you may need to insert the center console main body as close to the car front as possible, push the rear main body down if it conflicts with the cup area (the center console rear side is soft which can be pushed)



3. Mounting side leather baffle gently



4. Installation of the grid



Note: When install it you may need to push it hard to insert the CCI (use a soft cloth to protect your armrest area), that is how CCI are designed otherwise it may shake or move when driving.

